

**From:** Karyna Shuliak <[REDACTED]>

**To:** Karyna Shuliak <[REDACTED]>

**Subject:** iMovie supported cameras - Apple Support

**Date:** Sat, 11 Aug 2018 18:36:07 +0000

**Inline-Images:** hero-imovie-4k-camera.jpg; works-with-imovie-2016.png; divider.png

---

<https://support.apple.com/en-us/HT204202>

## iMovie supported cameras

iMovie is designed to work with a wide range of camcorders and digital still cameras, plus all models of iPhone, iPad, and iPod touch. And now, when you record 4K videos, you can use iMovie to turn them into amazing 4K movies.

[View 4K cameras >](#)   [View all cameras >](#)



Select a camera manufacturer below to see which models are compatible with iMovie.

### **Canon EOS 5D Mark IV**

Format: H.264 / MJPEG

Media: Memory

Region: Multi-Region

### **Canon EOS 6D Mark II**

Format: H.264

Media: Memory

Region: Multi-Region

### **Canon EOS M50**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon VIXIA GX10**

Format: H.264 / XF-AVC  
Media: Memory  
Region: Multi-Region

**Canon XF400**

Format: H.264 / XF-AVC  
Media: Memory  
Region: Multi-Region

**Canon XF405**

Format: H.264 / XF-AVC  
Media: Memory  
Region: Multi-Region

**DJI Inspire 1**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Inspire 1 Pro**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Inspire 1 v2.0**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Inspire 2 w/X4S**

Format: H.264 / H.265

Media: Memory  
Region: Multi-Region

**DJI Inspire 2 w/X5S**

Format: H.264 / ProRes / H.265  
Media: Memory  
Region: Multi-Region

**DJI Mavic Air**

Format: H.264  
Media: HDD / Memory  
Region: Multi-Region

**DJI Mavic Pro**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Osmo**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Phantom 3 Professional**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Phantom 4**

Format: H.264  
Media: Memory  
Region: Multi-Region

**DJI Phantom 4 Pro**

Format: H.264 / H.265

Media: Memory  
Region: Multi-Region

### **DJI Phantom 4 Pro V2.0**

Format: H.264 / H.265  
Media: Memory  
Region: Multi-Region

### **Fujifilm X-T2**

Format: H.264  
Media: Memory  
Region: Multi-Region

### **Fujifilm X-T20**

Format: H.264  
Media: Memory  
Region: Multi-Region

### **GoPro HERO3+ Black Edition**

Format: H.264  
Media: Memory  
Region: Multi-Region

### **GoPro HERO4 Black**

Format: H.264  
Media: Memory  
Region: Multi-Region

### **GoPro HERO4 Silver**

Format: H.264  
Media: Memory  
Region: Multi-Region

### **GoPro HERO5 Black**

Format: H.264

Media: Memory  
Region: Multi-Region

**GoPro HERO5 Session**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO6 Black**

Format: H.264 / H.265  
Media: Memory  
Region: Multi-Region

**GoPro Karma with HERO5 Black**

Format: H.264  
Media: Memory  
Region: Multi-Region

**JVC GZ-RY980**

Format: H.264 / AVCHD  
Media: HDD / Memory  
Region: NTSC, PAL

**Leica D-LUX (Typ 109)**

Format: H.264  
Media: Memory  
Region: NTSC

**Leica V-LUX (Typ 114)**

Format: H.264  
Media: Memory  
Region: NTSC

**Nikon COOLPIX B700**

Format: H.264

Media: Memory  
Region: Multi-Region

**Nikon D5**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D500**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D850**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D7500**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Olympus OM-D E-M1 Mark II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Olympus OM-D E-M10 Mark III**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Olympus Tough TG-5**

Format: H.264

Media: Memory  
Region: Multi-Region

**Panasonic AG-UX90**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic AG-UX180**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic DC-FT7**

Format: H.264  
Media: Memory  
Region: PAL

**Panasonic DC-FZ80**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-FZ82**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic DC-FZ85**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic DC-G9**

Format: AVCHD / H.264 / H.265

Media: Memory  
Region: NTSC, PAL

**Panasonic DC-G9L**

Format: AVCHD / H.264 / H.265  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-G9M**

Format: AVCHD / H.264 / H.265  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-GF9**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-GF10**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-GH5**

Format: AVCHD / H.264 / H.265  
Media: Memory  
Region: Multi-Region

**Panasonic DC-GH5S**

Format: AVCHD / H.264 / H.265  
Media: Memory  
Region: Multi-Region

**Panasonic DC-GX7MK3**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic DC-GX9**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-GX800**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-GX850**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic DC-TS7**

Format: H.264

Media: Memory

Region: NTSC / PAL

**Panasonic DC-TZ90**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-TZ91**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ92**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ93**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-ZS70**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FZ300**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FZ330**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FZ1000**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic DMC-FZ2000**

Format: AVCHD / H.264

Media: Memory

Region: Multi-Region

**Panasonic DMC-FZ2500**

Format: AVCHD / H.264

Media: Memory  
Region: Multi-Region

**Panasonic DMC-FZH1**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic DMC-G7**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G8**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G80**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G81**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G85**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX8**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GF8**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GH4**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX7 Mark II**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX80**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX85**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX9**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX10**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX15**

Format:AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX100**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL NTSC

**Panasonic DMC-TX1**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-TX2**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic DMC-TZ80**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ81**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ85**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ100**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ101**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ110**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-TZ200**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic DC-TZ202**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic DC-TZ220**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic DMC-ZS60**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS100**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS110**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-ZS200**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic GC-GX800**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic HC-PV100**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic HC-V385**

Format: AVCHD / H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-V785**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V800**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-V808**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-VX11**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-VXF1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX980**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VX980M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-VX981**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX985**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VX985M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX989**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VXF990**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VX990M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-VXF995**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VXF999**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-VZX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-VZX990M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-W585**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-W585M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-WX990M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-WX995M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-WXF1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF990**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF990M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-WXF991**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory  
Region: NTSC, PAL

**Panasonic HC-WXF995**

Format: AVCHD / H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-WXF995M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-WZX1M**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic HC-WZXF1M**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic HC-X1**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic HC-X1000**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic HC-WX970M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

### **Panasonic HC-VX870**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

### **Panasonic HX-A500**

Format: H.264

Media: Memory

Region: NTSC, PAL

### **Sony Alpha ILCE-7RM2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

### **Sony Alpha ILCE-7SM2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony DSC-RX10M2**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

### **Sony DSC-RX10M3**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony DSC-RX10M4**

Format: AVCHD / XAVC S

Media: Memory  
Region: Multi-Region

**Sony DSC-RX100M4**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: NTSC, PAL

**Sony DSC-RX100M5**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony DSC-RX100M6**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony FDR-AX1**

Format: AVCHD / XAVC S  
Media: Memory  
Region: NTSC, PAL

**Sony FDR-AX40**

Format: AVCHD / H.264 / XAVC S  
Media: HDD / Memory  
Region: NTSC, PAL

**Sony FDR-AX45**

Format: AVCHD / XAVC S  
Media: HDD / Memory  
Region: NTSC, PAL

**Sony FDR-AX53**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

### **Sony FDR-AX55**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

### **Sony FDR-AX60**

Format: AVCHD / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

### **Sony FDR-AX100**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

### **Sony FDR-AX700**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

### **Sony FDR-AXP55**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

### **Sony FDR-X1000V**

Format: H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony FDR-X3000**

Format: AVCHD / H.264 / XAVC S

Media: Memory  
Region: Multi-Region

**Sony HDR-AS300**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony HXR-NX80**

Format: AVCHD / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony ILCA-99M2**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony Alpha ILCE-6300**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony ILCE-9**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony ILCE-6500**

Format: AVCHD / H.264 / XAVC S  
Media: Memory  
Region: Multi-Region

**Sony ILCE-7M3**

Format: AVCHD / XAVC S

Media: Memory  
Region: Multi-Region

**Sony ILCE-7RM3**

Format: AVCHD / XAVC S  
Media: Memory  
Region: Multi-Region

**ZeroZero Hover Camera**

Format: H.264  
Media: HDD  
Region: NTSC



**Canon EOS 5D Mark II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 5D Mark III**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon EOS 5D Mark IV**

Format: H.264 / MJPEG  
Media: Memory  
Region: Multi-Region

**Canon EOS 5DS**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 5DS R**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon EOS 6D Mark II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 7D**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 7D Mark II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 77D**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS 80D**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS M3**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS M5**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon EOS M10**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS M50**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS M100**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel SL2**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T6**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T6s**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T6i**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T7**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T7i**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS Rebel T100**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon EOS SL1**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 145**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 147**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 150**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon IXUS 155**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 157**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 160**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 162**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 165**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 170**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 172**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon IXUS 175 (IXUS 177)**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 180 (IXUS 182)**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 185**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 190**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXUS 255 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXUS 265 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon IXUS 275 HS**

Format: H.264

Media: Memory  
Region: NTSC

**Canon IXUS 285 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon IXUS 310 HS**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXUS 500 HS**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXUS 510 HS**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 1**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 3**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 120**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon IXY 130**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 140**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 150**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 160**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 170**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 180**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 190**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon IXY 200**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 210**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon IXY 31S**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 32S**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 610F**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 620F**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon IXY 630**

Format: H.264

Media: Memory  
Region: NTSC

**Canon IXY 640**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon IXY 650**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot A810**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot A1300**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot A2300**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot A2400 IS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot A3400 IS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory  
Region: Multi-Region

**Canon PowerShot D30**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot ELPH 135**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot ELPH 140 IS**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot ELPH 150 IS**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot ELPH 160**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot ELPH 170 IS**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot ELPH 180**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 190 IS**

Format: H.264

Media: Memory

Region: Multi-Region

**Canon PowerShot ELPH 330 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 340 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 350 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 360 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 500 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 520 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot ELPH 530 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon Powershot G1 X**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot G1 X Mark II**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot G1 X Mark III**

Format: H.264

Media: Memory

Region: Multi-Region

**Canon Powershot G3**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon Powershot G3 X**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon Powershot G5 X**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory  
Region: Multi-Region

**Canon PowerShot G7 X**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot G7 X Mark II**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot G9 X**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot G9 X Mk II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot G12**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot G15**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot G16**

Format: H.264

Media: Memory

Region: NTSC

### **Canon Powershot N**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Canon PowerShot N100**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Canon Powershot S100**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Canon PowerShot S100 V**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Canon PowerShot S120**

Format: H.264

Media: Memory

Region: NTSC

### **Canon PowerShot S200**

Format: H.264

Media: Memory

Region: NTSC

### **Canon PowerShot SX60 HS**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon PowerShot SX170 IS**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Canon PowerShot SX220 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot SX230 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot SX240 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: HDD / Memory  
Region: NTSC

**Canon PowerShot SX260 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: HDD / Memory  
Region: NTSC

**Canon PowerShot SX270 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot SX275 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot SX280 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot SX400 IS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot SX410 IS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon PowerShot SX412 IS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon PowerShot SX420 IS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot SX430 IS**

Format: H.264

Media: Memory

Region: Multi-Region

**Canon PowerShot SX432 IS**

Format: H.264

Media: Memory  
Region: Multi-Region

**Canon PowerShot SX510 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot SX520 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot SX530 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot SX540 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Canon PowerShot SX600 HS**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Canon PowerShot SX610 HS**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon PowerShot SX620 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot SX700 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot SX710 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Canon PowerShot SX720 HS**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon PowerShot SX730 HS**

Format: H.264

Media: Memory

Region: NTSC

**Canon PowerShot A1300**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon PowerShot A2300**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Canon PowerShot A1300**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

### **Canon PowerShot A2300**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region



### **Canon**

Format: HDV / DV

Media: Tape <sup>2</sup>

Region: Multi-Region

### **Canon EOS C100**

Format: AVCHD

Media: Memory

Region: Multi-Region

### **Canon iVIS HF G20**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

### **Canon iVIS HF G40**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

### **Canon iVIS HF M51**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC

### **Canon iVIS HF M52**

Format: AVCHD / H.264

Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R21**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R30**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R31**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R32**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R42**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R51**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R52**

Format: AVCHD / H.264

Media: HDD / Memory  
Region: NTSC

**Canon iVIS HF R62**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon iVIS Mini**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon LEGRIA FS46**

Format: MPEG-2  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF100**

Format: AVCHD  
Media: Memory  
Region: PAL

**Canon LEGRIA HF G10**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF G25**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF G30**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Canon LEGRIA HF G40**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Canon LEGRIA HF M31**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF M52**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF M56**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF M60**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF M506**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R28**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R36**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R37**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R38**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R306**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R46**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R47**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R48**

Format: AVCHD / H.264

Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R56**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R57**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R66**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R67**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R68**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R76**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: PAL

**Canon LEGRIA HF R77**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R78**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R88**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R406**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R506**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Canon LEGRIA HF R600**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Canon LEGRIA HF R706**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Canon LEGRIA HF S200**

Format: AVCHD

Media: Memory

Region: PAL

**Canon LEGRIA HG10**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Canon LEGRIA Mini**

Format: H.264

Media: Memory

Region: PAL

**Canon VIXIA GX10**

Format: H.264 / XF-AVC

Media: Memory

Region: Multi-Region

**Canon VIXIA HF100**

Format: AVCHD

Media: Memory

Region: Multi-Region

**Canon VIXIA HF11**

Format: AVCHD

Media: Memory

Region: NTSC

**Canon VIXIA HF G10**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

**Canon VIXIA HF G20**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF G30**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Canon VIXIA HF G40**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Canon VIXIA HF M31**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF M50**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF M52**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF M500**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R30**

Format: AVCHD / H.264

Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R32**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R40**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R42**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R50**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R52**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R60**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R62**

Format: AVCHD / H.264

Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R82**

Format: H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R300**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R400**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R500**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R600**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Canon VIXIA HF S10**

Format: AVCHD  
Media: Memory  
Region: NTSC

**Canon VIXIA HF S200**

Format: AVCHD

Media: Memory  
Region: NTSC

**Canon VIXIA HF100**

Format: AVCHD  
Media: Memory  
Region: NTSC

**Canon VIXIA HG10**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA Mini**

Format: H.264  
Media: Memory  
Region: NTSC

**Canon VIXIA HF R70**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R72**

Format: AVCHD / H.264  
Media: HDD / Memory  
Region: NTSC

**Canon VIXIA HF R700**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Canon XA10 A**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**Canon XA10 E**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**Canon XA20**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Canon XA25**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Canon XA30**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Canon XA35**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Canon XF400**

Format: H.264 / XF-AVC  
Media: Memory  
Region: Multi-Region

**Canon XF405**

Format: H.264 / XF-AVC

Media: Memory  
Region: Multi-Region



**Casio EX-FC300S**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR1000**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR15**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR20**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR200**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR300**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR310**

Format: H.264

Media: Memory  
Region: NTSC

**Casio EX-ZR400**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EX-ZR700**

Format: H.264  
Media: Memory  
Region: NTSC

**Casio EZ-ZR410**

Format: H.264  
Media: Memory  
Region: NTSC



**Cisco Flip Mino HD**

Format: H.264  
Media: Memory  
Region: NTSC

**Cisco Flip Ultra HD**

Format: H.264  
Media: Memory  
Region: NTSC

**Cisco Flip Ultra HD 3**

Format: H.264  
Media: Memory  
Region: NTSC



**Contour +2 1700**

Format: H.264

Media: Memory

Region: Multi-Region

**Contour GPS 1400**

Format: H.264

Media: Memory

Region: Multi-Region

**Contour Plus 1529**

Format: H.264

Media: Memory

Region: Multi-Region

**Contour ROAM2**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Inspire 1**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Inspire 1 Pro**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Inspire 1 v2.0**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Inspire 2 w/X4S**

Format: H.264 / H.265

Media: Memory

Region: Multi-Region

**DJI Inspire 2 w/X5S**

Format: H.264 / ProRes / H.265

Media: Memory

Region: Multi-Region

**DJI Mavic Air**

Format: H.264

Media: HDD / Memory

Region: Multi-Region

**DJI Mavic Pro**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Phantom 3 Advanced**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Phantom 3 Standard**

Format: H.264

Media: Memory

Region: Multi-Region

**DJI Phantom 3 Professional**

Format: H.264

Media: Memory

Region: Multi-Region

## **DJI Phantom 4**

Format: H.264

Media: Memory

Region: Multi-Region

## **DJI Phantom 4 Pro**

Format: H.264 / H.265

Media: Memory

Region: Multi-Region

## **DJI Phantom 4 Pro V2.0**

Format: H.264 / H.265

Media: Memory

Region: Multi-Region

## **DJI Spark**

Format: H.264

Media: Memory

Region: NTSC



## **DJI camcorders**

### **DJI Osmo**

Format: H.264

Media: Memory

Region: Multi-Region



## **DxO**

### **DxO One**

Format: H.264

Media: Memory

Region: NTSC



### **Fujifilm GFX-50S**

Format: H.264

Media: Memory

Region: Multi-Region

### **Fujifilm X70**

Format: H.264

Media: Memory

Region: Multi-Region

### **Fujifilm X100F**

Format: H.264

Media: Memory

Region: Multi-Region

### **Fujifilm X100T**

Format: H.264

Media: Memory

Region: Multi-Region

### **Fujifilm X-A2**

Format: H.264

Media: Memory

Region: NTSC

### **Fujifilm X-A3**

Format: H.264

Media: Memory

Region: Multi-Region

### **Fujifilm X-A10**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X-E2S**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X-Pro1**

Format: H.264

Media: Memory

Region: NTSC

**Fujifilm X-Pro2**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X-T2**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X-T10**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X-T20**

Format: H.264

Media: Memory

Region: Multi-Region

**Fujifilm X20**

Format: H.264

Media: Memory

Region: NTSC

## **Fujifilm X30**

Format: H.264

Media: Memory

Region: Multi-Region



## **Garmin VIRB Elite**

Format: H.264

Media: Memory

Region: NTSC



## **GoPro HERO**

Format: H.264

Media: Memory

Region: Multi-Region

## **GoPro HERO+**

Format: H.264

Media: Memory

Region: Multi-Region

## **GoPro HERO3 Black Edition**

Format: H.264

Media: Memory

Region: Multi-Region

## **GoPro HERO3 Silver Edition**

Format: H.264

Media: Memory

Region: Multi-Region

## **GoPro HERO3 White Edition**

Format: H.264

Media: Memory  
Region: Multi-Region

**GoPro HERO3+ Black Edition**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO3+ Silver Edition**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO4 Session**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO4 Silver**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO4 Black**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO5 Black**

Format: H.264  
Media: Memory  
Region: Multi-Region

**GoPro HERO5 Session**

Format: H.264

Media: Memory

Region: Multi-Region

### **GoPro HERO6 Black**

Format: H.264 / H.265

Media: Memory

Region: Multi-Region

### **GoPro HERO+ LCD**

Format: H.264

Media: Memory

Region: Multi-Region



## **GoPro drones**

### **GoPro Karma with HERO5 Black**

Format: H.264

Media: Memory

Region: Multi-Region



### **Hasselblad Lunar**

Format: AVCHD / H.264

Media: Memory

Region: PAL



### **JVC**

Format: HDV / DV

Media: Tape <sup>2</sup>

Region: Multi-Region

### **JVC GC-FM2**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**JVC GC-P100**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**JVC GC-PX100**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**JVC GC-XA1-B**

Format: H.264

Media: Memory

Region: NTSC

**JVC GC-XA1BEU**

Format: H.264

Media: Memory

Region: PAL

**JVC GC-XA1BUS**

Format: H.264

Media: Memory

Region: NTSC

**JVC GC-YJ40**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

**JVC GZ-B800**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-E60**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E66**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E77**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E80**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E100**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E105**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E107**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-E108**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E109**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E110**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E140**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E150**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E155**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E170**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-E235**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E239**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E241**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E242**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E300**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E305**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E306**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-E307**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E308**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E309**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E311**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E320**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E325**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E333**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-E345**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E355**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E369**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-E380**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E400**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E505**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E509**

Format: AVCHD

Media: Memory  
Region: PAL

**JVC GZ-E565**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-E595**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E600**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E690**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E700**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E745**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E750**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-E765**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-E770**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-E780**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-EJ1**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-EX310**

Format: AVCHD / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-EX315**

Format: AVCHD / iFrame <sup>1</sup>  
Media: Memory  
Region: PAL

**JVC GZ-EX350**

Format: AVCHD / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**JVC GZ-EX355**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**JVC GZ-EX370**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-EX380**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC

**JVC GZ-EX510**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-EX515**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**JVC GZ-EX555**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**JVC GZ-EX575**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-E88o**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

**JVC GZ-F5o**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

**JVC GZ-F55K**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

**JVC GZ-F1oo**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**JVC GZ-F117**

Format: AVCHD

Media: Memory

Region: NTSC

**JVC GZ-F125**

Format: AVCHD

Media: Memory

Region: PAL

**JVC GZ-F17o**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-F200**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-F270**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-F280**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-GX100**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-HH140**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-HM133**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM155**

Format: AVCHD

Media: Memory  
Region: NTSC

**JVC GZ-HM177**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM199**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM300S**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM45**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM65**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-HM99**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-L330**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-L500**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-L550**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-L660**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-N1**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-N11**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-N5**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R10**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC, PAL

**JVC GZ-R12**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R15**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R18**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R30**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R50**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R70**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R75K**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-R280**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-R300**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R310**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R315**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R318**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R320**

Format: AVCHD  
Media: Memory  
Region: NTSC, PAL

**JVC GZ-R400**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-R401**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R405**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R410**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R415**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R420**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-R428**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R430**

Format: AVCHD

Media: HDD / Memory  
Region: PAL

**JVC GZ-R435**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R440**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-R450**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R460**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R465**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-R470**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R480**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-R495**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-R550**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-R560**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX110**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX115**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX120**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX130**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX500**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX510**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-RX515**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-RX520**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX530**

Format: AVCHD  
Media: Memory  
Region: PAL

**JVC GZ-RX600**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX601**

Format: AVCHD

Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX605**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX610**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX615**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX620**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX630**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX640**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX645**

Format: AVCHD

Media: HDD / Memory  
Region: PAL

**JVC GZ-RX650**

Format: AVCHD  
Media: HDD / Memory  
Region: PAL

**JVC GZ-RX670**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RX680**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC

**JVC GZ-RY980**

Format: H.264 / AVCHD  
Media: HDD / Memory  
Region: NTSC, PAL

**JVC GZ-V605**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-V675-T**

Format: AVCHD  
Media: Memory  
Region: NTSC

**JVC GZ-VX810**

Format: AVCHD / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-VX815**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**JVC GZ-VX855**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-VX875**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**JVC GZ-VX895**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC

**JVC JY-HM70**

Format: AVCHD

Media: Memory

Region: PAL

**JVC JY-HM85**

Format: AVCHD

Media: Memory

Region: PAL



**Leica C**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Leica D-LUX 6**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC

**Leica D-LUX (TYP 109)**

Format: H.264

Media: Memory

Region: NTSC

**Leica M**

Format: MJPEG

Media: Memory

Region: Multi-Region

**Leica Q (Typ 116)**

Format: H.264

Media: Memory

Region: NTSC

**Leica T**

Format: H.264

Media: Memory

Region: NTSC

**Leica V-LUX (TYP 114)**

Format: H.264

Media: Memory

Region: NTSC

**Leica V-LUX 40**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Leica X (TYP 113)**

Format: H.264

Media: Memory

Region: NTSC



**Nikon 1 J3**

Format: H.264

Media: Memory

Region: NTSC

**Nikon 1 J4**

Format: H.264

Media: Memory

Region: NTSC

**Nikon 1 S1**

Format: H.264

Media: Memory

Region: NTSC

**Nikon 1 S2**

Format: H.264

Media: Memory

Region: NTSC

**Nikon 1 V3**

Format: H.264

Media: Memory

Region: NTSC

**Nikon COOLPIX AW110**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX AW110s**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX AW120**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon COOLPIX AW120s**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon COOLPIX B700**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon COOLPIX L620**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX L820**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX L830**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory  
Region: Multi-Region

**Nikon COOLPIX P330**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Nikon COOLPIX P340**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Nikon COOLPIX P520**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Nikon COOLPIX P530**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Nikon COOLPIX P600**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: Multi-Region

**Nikon COOLPIX S02**

Format: H.264 / iFrame <sup>1</sup>  
Media: Memory  
Region: NTSC

**Nikon COOLPIX S5200**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX S5300**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Nikon COOLPIX S6500**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX S6600**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX S6800**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon COOLPIX S6900**

Format: H.264

Media: Memory

Region: NTSC

**Nikon COOLPIX S9400**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Nikon COOLPIX S9500**

Format: H.264 / iFrame

Media: Memory

Region: NTSC

**Nikon COOLPIX S9600**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Nikon COOLPIX S9700s**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: Multi-Region

**Nikon D4**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon D5**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon D90**

Format: MJPEG

Media: Memory

Region: NTSC

**Nikon D500**

Format: H.264

Media: Memory

Region: Multi-Region

**Nikon D750**

Format: H.264

Media: Memory  
Region: Multi-Region

**Nikon D810**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D850**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D3400**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D5600**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D7100**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D7200**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Nikon D7500**

Format: H.264

Media: Memory  
Region: Multi-Region



**Olympus E-PL6**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus OM-D E-M1**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus OM-D E-M1 Mark II**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Olympus OM-D E-M5**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus OM-D E-M10**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus OM-D E-M5 Mark II**

Format: H.264 / MJPEG  
Media: Memory  
Region: Multi-Region

**Olympus OM-D E-M10 Mark III**

Format: H.264

Media: Memory  
Region: Multi-Region

**Olympus PEN E-P3**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-P5**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-PL3**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-PL5**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-PL7**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-PL8**

Format: H.264 / MJPEG  
Media: Memory  
Region: NTSC

**Olympus PEN E-PM2**

Format: H.264 / MJPEG

Media: Memory

Region: NTSC

**Olympus PEN-F**

Format: H.264 / MJPEG

Media: Memory

Region: Multi-Region

**Olympus Stylus SH-2**

Format: H.264

Media: Memory

Region: NTSC

**Olympus Stylus TG-4**

Format: H.264 / MJPEG

Media: Memory

Region: NTSC

**Olympus Tough TG-5**

Format: H.264

Media: Memory

Region: Multi-Region



**Panasonic DC-FT7**

Format: H.264

Media: Memory

Region: PAL

**Panasonic DC-FZ80**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-FZ82**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-FZ85**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic DC-G9**

Format: AVCHD / H.264 / H.265

Media: Memory

Region: NTSC, PAL

**Panasonic DC-G9L**

Format: AVCHD / H.264 / H.265

Media: Memory

Region: NTSC, PAL

**Panasonic DC-G9M**

Format: AVCHD / H.264 / H.265

Media: Memory

Region: NTSC, PAL

**Panasonic DC-GF9**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-GF10**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-GH5**

Format: AVCHD / H.264 / H.265

Media: Memory  
Region: Multi-Region

**Panasonic DC-GH5S**

Format: AVCHD / H.264 / H.265  
Media: Memory  
Region: Multi-Region

**Panasonic DC-GX7MK3**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic DC-GX9**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DC-GX800**

Format: AVCHD / H.264  
Media: Memory  
Region: PAL

**Panasonic DC-GX850**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic DC-TS7**

Format: H.264  
Media: Memory  
Region: NTSC / PAL

**Panasonic DC-TX2**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic DC-TZ90**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-TZ91**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ92**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ93**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ200**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ202**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-TZ220**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic DC-ZS70**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DC-ZS200**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC AG-GH4**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-F5**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-FH10**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-FH2**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-FS16**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-FS50**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-FT2**

Format: AVCHD / MJPEG

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FT3**

Format: AVCHD / MJPEG

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FT5**

Format: AVCHD / MJPEG

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FT6**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FT30**

Format: H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-FX700**

Format: AVCHD / MJPEG

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ60**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ62**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ70**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ72**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ200**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ300**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ330**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ1000**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-FZ2000**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic DMC-FZ2500**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic DMC-FZH1**

Format: AVCHD / H.264  
Media: Memory  
Region: Multi-Region

**Panasonic DMC-G2**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G3**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G5**

Format: AVCHD / MJPEG

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G6**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G7**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G8**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G70**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G80**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G81**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-G85**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GF5**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GF6**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GF7**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GF8**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GH2**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GH3**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GH4**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GM1**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GM5**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX1**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX7**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX7 Mark II**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX8**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX80**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-GX85**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LF1**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX5**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX7**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX9**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX10**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX15**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LX100**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-LZ20**

Format: MJPEG  
Media: Memory  
Region: NTSC

**Panasonic DMC-LZ30**

Format: MJPEG  
Media: Memory  
Region: NTSC

**Panasonic DMC-LZ40**

Format: MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-SZ8**

Format: MJPEG  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic DMC-SZ9**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-SZ10**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-TS2**

Format: AVCHD / MJPEG

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TS3**

Format: AVCHD / MJPEG

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TS5**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TS6**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TS30**

Format: H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TX1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TZ18**

Format: MJPEG

Media: Memory

Region: NTSC

**Panasonic DMC-TZ35**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TZ36**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TZ37**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TZ40**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic DMC-TZ41**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic DMC-TZ55**

Format: H.264

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic DMC-TZ56**

Format: H.264

Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ57**

Format: H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ58**

Format: H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ60**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ61**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ70**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ71**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ80**

Format: AVCHD / H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ81**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ85**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ100**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ101**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-TZ110**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-XS1**

Format: MJPEG  
Media: Memory  
Region: NTSC

**Panasonic DMC-XS3**

Format: H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS10**

Format: AVCHD / MJPEG  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS25**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS27**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS30**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS35**

Format: H.264  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS40**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS45**

Format: H.264

Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS50**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS60**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS100**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic DMC-ZS110**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic GC-GX800**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL



**Panasonic**

Format: HDV / DV  
Media: Tape <sup>2</sup>  
Region: Multi-Region

**Panasonic AG-AC8PJ**

Format: AVCHD

Media: Memory

Region: NTSC

**Panasonic AG-UX90**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic AG-UX180**

Format: AVCHD / H.264

Media: Memory

Region: Multi-Region

**Panasonic HC-MDH2**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Panasonic HC-MDH2M**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Panasonic HC-MDH3E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-MDH3PP**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-PV100**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-V110**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V130**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V180**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V201**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-V210**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V210M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V230**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V230M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-V250**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V330M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-V360MS**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-V380**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V385**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V480M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-V480MS**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-V510**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V520**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V520M**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V530**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V550**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V550M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V620M**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-V710**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-V720**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V720M**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V727**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-V730**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-V750**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V750M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-V757**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-V760**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V770**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-V770M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-V777**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V785**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-V800**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-V808**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-VX11**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Panasonic HC-VXF1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-VX870**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory  
Region: NTSC, PAL

**Panasonic HC-VX870M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HC-VX878**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VX980**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VX980M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HC-VX981**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC, PAL

**Panasonic HC-VX985**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VX985M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: Memory  
Region: NTSC, PAL

**Panasonic HC-VX989**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VX990M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC

**Panasonic HC-VXF990**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VXF995**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VXF999**

Format: AVCHD / H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-VZX1M**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC

**Panasonic HC-VZX990M**

Format: AVCHD / H.264 / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

### **Panasonic HC-W570**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

### **Panasonic HC-W570M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

### **Panasonic HC-W580**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

### **Panasonic HC-W580M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

### **Panasonic HC-W585**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

### **Panasonic HC-W585M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

### **Panasonic HC-W850**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-W850M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-W858**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HC-WX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-WX970**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WX979**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-WX970M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-WX990M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HC-WXF1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF990**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF991**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-WXF990M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HC-WX995M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HC-WXF995**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-WXF995M**

Format: AVCHD / H.264 / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-WZX1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-WZXF1M**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Panasonic HC-X1**

Format: AVCHD / H.264

Media: Memory

Region: Multi-Region

**Panasonic HC-X800**

Format: AVCHD / iFrame <sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HC-X810**

Format: AVCHD / iFrame <sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HC-X900**

Format: AVCHD / iFrame <sup>1</sup>

Media: Memory  
Region: NTSC, PAL

**Panasonic HC-X900M**

Format: AVCHD / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC, PAL

**Panasonic HC-X1000**

Format: AVCHD / H.264  
Media: Memory  
Region: NTSC, PAL

**Panasonic HC-X909**

Format: AVCHD / iFrame<sup>1</sup>  
Media: Memory  
Region: PAL

**Panasonic HC-X910**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HC-X920**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HC-X920M**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HC-X929**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: PAL

**Panasonic HDC-HS900**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HDC-SD40**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HDC-SD41**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HDC-SD800**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HDC-SD9**

Format: AVCHD

Media: Memory

Region: PAL

**Panasonic HDC-SD90**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: NTSC, PAL

**Panasonic HDC-SD900**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HDC-SD909**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HDC-SD99**

Format: AVCHD / iFrame<sup>1</sup>

Media: Memory

Region: PAL

**Panasonic HDC-SD9P**

Format: AVCHD

Media: Memory

Region: NTSC

**Panasonic HDC-TM25**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HDC-TM40**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC, PAL

**Panasonic HDC-TM41**

Format: AVCHD / iFrame<sup>1</sup>

Media: HDD / Memory

Region: NTSC

**Panasonic HDC-TM60**

Format: AVCHD

Media: Memory  
Region: NTSC, PAL

**Panasonic HDC-TM700**

Format: AVCHD  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HDC-TM85**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC

**Panasonic HDC-TM90**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HDC-TM900**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic HDC-TM99**

Format: AVCHD / iFrame<sup>1</sup>  
Media: HDD / Memory  
Region: PAL

**Panasonic HM-TA1**

Format: H.264 / iFrame<sup>1</sup>  
Media: Memory  
Region: NTSC

**Panasonic HX-A1**

Format: H.264

Media: Memory

Region: NTSC

**Panasonic HX-A100**

Format: H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HX-A500**

Format: H.264

Media: Memory

Region: NTSC, PAL

**Panasonic HX-DC3**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HX-WA03**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HX-WA3**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic HX-WA30**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

**Panasonic SDR-H100**

Format: MPEG-2

Media: HDD / Memory  
Region: NTSC, PAL

**Panasonic SDR-H101**

Format: MPEG-2  
Media: HDD / Memory  
Region: NTSC, PAL



**Parrot Bebop 2**

Format: H.264  
Media: HDD  
Region: NTSC

**Parrot Disco FPV**

Format: H.264  
Media: HDD  
Region: Multi-Region

**Parrot Jumping Night**

Format: MJPEG  
Media: HDD  
Region: NTSC

**Parrot Jumping Race**

Format: MJPEG  
Media: HDD  
Region: NTSC

**Pentax K-1**

Format: H.264  
Media: Memory  
Region: Multi-Region

**Pentax K-3 II**

Format: H.264

Media: Memory

Region: Multi-Region

**Pentax K-5 II**

Format: MJPEG

Media: Memory

Region: Multi-Region

**Pentax K-5 IIs**

Format: MJPEG

Media: Memory

Region: Multi-Region

**Pentax K-S1**

Format: H.264

Media: Memory

Region: Multi-Region

**Pentax K-S2**

Format: H.264

Media: Memory

Region: Multi-Region

**Pentax KP**

Format: H.264

Media: Memory

Region: Multi-Region

**Sanyo VPC-CA9**

Format: H.264

Media: Memory

Region: NTSC

### **Sanyo VPC-FH1**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Sanyo VPC-HD2000A**

Format: H.264 / iFrame <sup>1</sup>

Media: Memory

Region: NTSC

### **Sanyo VPC-PD2BK**

Format: H.264

Media: Memory

Region: NTSC



### **Sony Alpha ILCE-3000**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

### **Sony Alpha ILCE-5000**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

### **Sony Alpha ILCE-5100**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

### **Sony Alpha ILCE-6000**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha ILCE-7**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha ILCE-7M2**

Format: XAVC S / AVCHD / H.264

Media: Memory

Region: NTSC

**Sony Alpha ILCE-7R**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha SLT-A35**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony Alpha SLT-A37**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha SLT-A55V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony Alpha SLT-A55VE**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony Alpha SLT-A57**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha SLT-A58**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony Alpha SLT-A65V**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony Alpha SLT-A77V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony Alpha SLT-A99**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony Alpha SLT-A99V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-H100**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-H55**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-H90**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-HX1**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-HX10**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX10V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX80**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX300**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX350**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX400**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX400V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX50**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX50V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX60**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX60V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-HX90V**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony DSC-J20**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-QX10**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-QX100**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-RX0**

Format: AVCHD / XAVC S / H.264

Media: Memory

Region: Multi-Region

**Sony DSC-RX1**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX10**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX10M3**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony DSC-RX10M4**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony DSC-RX100**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX100M2**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX100M3**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

**Sony DSC-RX100M5**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony DSC-RX100M6**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony DSC-RX1R**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX1RM2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony DSC-RX10M2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony DSC-RX100M4**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony DSC-TF1**

Format: MJPEG

Media: Memory

Region: NTSC

**Sony DSC-TX10**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-TX100**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-TX100V**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-TX20**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Sony DSC-TX30**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-TX66**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony DSC-W380**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W390**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W630**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W650**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W670**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W690**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W730**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-W830**

Format: H.264

Media: Memory

Region: NTSC

**Sony DSC-WX10**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-WX100**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX150**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX170**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX200**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX220**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-WX300**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX350**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony DSC-WX50**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX500**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony DSC-WX60**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX70**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony DSC-WX80**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC, PAL

**Sony Alpha ILCA-68**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

**Sony Alpha ILCE-7RM2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC, PAL

**Sony Alpha ILCE-7S**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

### **Sony Alpha ILCE-7SM2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony Alpha ILCA-77M2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

### **Sony ILCA-99M2**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony Alpha ILCE-6300**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony ILCE-9**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony ILCE-6500**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

### **Sony ILCE-7M3**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony ILCE-7RM3**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony NEX-3N**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-5**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-5N**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-5R**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-5T**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-6**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-7**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony NEX-C3**

Format: H.264

Media: Memory

Region: NTSC

**Sony NEX-F3**

Format: AVCHD / H.264

Media: Memory

Region: NTSC, PAL

**Sony**

Format: HDV / DV

Media: Tape <sup>2</sup>

Region: Multi-Region

**Sony DCR-SR100**

Format: MPEG-2

Media: HDD

Region: NTSC

**Sony DCR-SR100E**

Format: MPEG-2

Media: HDD

Region: PAL

**Sony DCR-SR58E**

Format: MPEG-2

Media: HDD

Region: PAL

**Sony DCR-SR68**

Format: MPEG-2

Media: HDD

Region: NTSC

**Sony DCR-SR68E**

Format: MPEG-2

Media: HDD

Region: PAL

**Sony DCR-SR78E**

Format: MPEG-2

Media: HDD

Region: PAL

**Sony DCR-SR88**

Format: MPEG-2

Media: HDD

Region: NTSC

**Sony DCR-SR88E**

Format: MPEG-2

Media: HDD

Region: PAL

**Sony FDR-X1000V**

Format: H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony FDR-X3000**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony HDR-AS10**

Format: H.264

Media: Memory

Region: NTSC

**Sony HDR-AS15**

Format: H.264

Media: Memory

Region: NTSC

**Sony HDR-AS30**

Format: H.264

Media: Memory

Region: Multi-Region

**Sony HDR-AS30V**

Format: H.264

Media: Memory

Region: Multi-Region

**Sony HDR-AS50**

Format: H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony HDR-AS300**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony FDR-AX1**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony FDR-AX40**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony FDR-AX45**

Format: AVCHD / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony FDR-AX53**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony FDR-AX60**

Format: AVCHD / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony FDR-AX100**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: Multi-Region

**Sony FDR-AX700**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony FDR-AXP55**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony HDR-CX110**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX110E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX115E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX116E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX12**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

**Sony HDR-CX120**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX12E**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL

**Sony HDR-CX150**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX150E**

Format: AVCHD

Media: HDD / Memory

Region: PAL

**Sony HDR-CX155E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX170**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX190**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX190E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX200**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX200E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX210**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX210E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX220**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX220E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX230**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX230E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX240**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-CX240E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-CX250**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX250E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX260E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX260V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX260VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX270E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX270V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX280**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX280E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX290**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX290E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX300**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX300E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX305E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX320**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX320E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX330**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-CX330E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-CX350**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony HDR-CX350E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony HDR-CX350V**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

**Sony HDR-CX350VE**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL

**Sony HDR-CX370V**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

**Sony HDR-CX380**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX380E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX390**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX390E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX400E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX410VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX420**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-CX430V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX430VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX450**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: NTSC

**Sony HDR-CX450E**

Format: AVCHD / H.264 / XAVC S

Media: Memory

Region: PAL

**Sony HDR-CX455**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX470**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony HDR-CX485**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX510E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX535**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-CX540**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-CX570E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX580E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX580V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX580VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX590V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX610E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-CX625E**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: PAL

**Sony HDR-CX630V**

Format: AVCHD / H.264 / MPEG-2

Media: Memory

Region: NTSC

**Sony HDR-CX675**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX680**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC, PAL

**Sony HDR-CX7**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

**Sony HDR-CX720V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX730E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX740VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX760E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX760V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-CX760VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-CX7EK**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL

**Sony HDR-GW55VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GW66E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GW66V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-GW66VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GW77**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-GW77E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GW77V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-GW77VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GWP88**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-GWP88E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-GWP88V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-GWP88VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-MV1**

Format: H.264

Media: Memory

Region: NTSC

**Sony HDR-PJ200**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ200E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ210**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ220**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ220E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ230**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ230E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ240**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-PJ240E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ260**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ260E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ260V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ260VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ270**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ270E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ275E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ30**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ30E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ30V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ30VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ320E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ330E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ340**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-PJ340E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ350E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ380**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ380E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ390**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ390E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ40V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ420E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ420VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ430**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ430E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ430V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ430VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ510E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ530E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ540**

Format: AVCHD / H.264

Media: Memory

Region: NTSC

**Sony HDR-PJ540E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ580**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ580E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ580V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ580VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ590V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ600**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ600E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ600V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ600VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ610E**

Format: AVCHD / H.264

Media: Memory

Region: PAL

**Sony HDR-PJ630V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ650E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ650V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ650VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ660**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ660E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ660V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ660VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ675**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ675E**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ680**

Format: AVCHD / H.264 / XAVC S

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ710**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ710V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ710VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ720E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ740VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ760**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ760E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ760V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ760VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ780E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ780VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ790**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ790E**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ790V**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ790VE**

Format: AVCHD / H.264 / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ800**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ810E**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Sony HDR-PJ820**

Format: AVCHD / H.264

Media: HDD / Memory

Region: NTSC

**Sony HDR-PJ820E**

Format: AVCHD / H.264

Media: HDD / Memory

Region: PAL

**Sony HDR-SR12**

Format: AVCHD

Media: HDD / Memory

Region: NTSC

**Sony HDR-SR12E**

Format: AVCHD

Media: HDD

Region: PAL

**Sony HDR-UX20**

Format: AVCHD

Media: DVD

Region: NTSC

**Sony HDR-UX20E**

Format: AVCHD

Media: DVD

Region: PAL

**Sony HDR-XR260E**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-XR260V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-XR260VE**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: PAL

**Sony HDR-XR520**

Format: AVCHD / MPEG-2

Media: HDD

Region: NTSC

**Sony HDR-XR520E**

Format: AVCHD / MPEG-2

Media: HDD

Region: PAL

**Sony HDR-XR520V**

Format: AVCHD / MPEG-2

Media: HDD / Memory

Region: NTSC

**Sony HDR-XR520VE**

Format: AVCHD / MPEG-2

Media: HDD

Region: PAL

**Sony HDR-XR550**

Format: AVCHD / MPEG-2

Media: HDD

Region: NTSC

**Sony HDR-XR550E**

Format: AVCHD / MPEG-2

Media: HDD

Region: PAL

**Sony HDR-XR550V**

Format: AVCHD / MPEG-2

Media: HDD

Region: NTSC

**Sony HDR-XR550VE**

Format: AVCHD / MPEG-2

Media: HDD

Region: PAL

**Sony HXR-NX5R**

Format: AVCHD / XAVC S

Media: Memory

Region: NTSC

**Sony HXR-NX80**

Format: AVCHD / XAVC S

Media: Memory

Region: Multi-Region

**Sony HXR-NX100**

Format: AVCHD / XAVC S

Media: Memory

Region: NTSC

**Sony MHS-FS2**

Format: H.264

Media: HDD

Region: NTSC

**Sony NEX-VG10**

Format: AVCHD

Media: Memory

Region: NTSC

**Sony NEX-VG10E**

Format: AVCHD

Media: Memory

Region: PAL

**Sony NEX-VG20**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

### **Sony NEX-VG20E**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL

### **Sony NEX-VG30**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

### **Sony NEX-VG30E**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL

### **Sony NEX-VG900**

Format: AVCHD / MPEG-2

Media: Memory

Region: NTSC

### **Sony NEX-VG900E**

Format: AVCHD / MPEG-2

Media: Memory

Region: PAL



### **ZeroZero Hover Camera**

Format: H.264

Media: HDD

Region: NTSC



## **Notes**

1 iFrame is a computer-friendly video format designed by Apple to optimize the process of working with video recorded with your camera or camcorder.

2 iMovie works with most mini DV tape-based camcorders using DV and HDV formats. Use FireWire port for tape-based devices.

## **Learn more**

To view supported devices for the previous version of iMovie, see: [iMovie '11](#).

Apple, the Apple logo, FireWire, iMovie, iPad, iPhone, iPod touch, Mac, and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries.

The Works with iMovie logo is a trademark of Apple Inc.

Disclaimer: This information reflects the devices we have inspected and approved for use with iMovie as of the date of publication. Apple does not guarantee the accuracy of this information nor assume any responsibility for the purchase decisions of users of this information. This list does not constitute Apple's recommendation or endorsement of any products not manufactured by Apple. Please contact the product vendor(s) for additional information regarding their respective products.