

To create a CD Extra CD, click either the Audio CD Layout icon or the Data CD Layout icon.

Add the music CD tracks, WAV, or MP3 files that you want to record to the Audio CD Layout; the files and folders to the Data CD Layout.