

430 PARTS AND PRICING

Part Number	Description	Quantity
430-010-105-105	Clamp See Notes	2
430-010-122-101	Stud	0
430-010-123-101	Plug	2
430-010-130-101	Shim	1
430-010-130-101	Shim .002	1
430-010-130-101	Shim .004	1
430-010-130-101	Shim .008	1
430-010-212-101	Mount Isolation Lateral	1
430-010-304-107	Weight, Tuning	2
430-010-304-113	Weight, Tuning	2
430-010-304-119	Weight, Tuning	2
430-010-408-101	Drive Link Assy	1
430-010-409-105	Link Assy Idler	1
430-010-412-105	Cyclic Link	1
430-010-412-106	Cyclic Link	1
430-010-429-101	Bushing	1
430-010-430-101	Bushing	2
430-010-433-101	Rod End	1
430-010-434-101	Swashplate Sheild	1
430-010-436-101	Shim	2
430-010-449-101	Swash Plate Bearing Assy	1
430-010-450-101	Race	4
430-010-463-101	Bushing	1
430-015-029-101	Weight	2
430-015-029-103	Weight	1
430-015-029-105	Weight	1
430-015-029-107	Weight	1
430-015-029-109	Weight	1
430-015-029-113	Weight	1
430-015-029-115	Weight	2
430-015-029-117	Weight	2
430-015-029-119	Weight	2
430-015-029-121	Weight	1
430-015-029-123	Weight	5
430-031-103-127	Spring	1
430-031-517-135S	Support	1
430-070-011-103	Plate, Avionics	2
430-070-031-169	Bus Bar	1
430-070-032-101	Panel, Aux Fuel	1
430-075-019-103	Panel W/Connector	1
430-075-101-125	Panel	2
430-310-101-107	Restraint, Shear X/R	3
430-310-456-101	Bearing	3

430 PARTS AND PRICING

Part Number	Description	Quantity
430-310-459-101	Bushing	4
430-705-800-119	Retainer	1
430-	Main Driveshaft Balancing Kit	1
222-012-711-107	Link, T/R Short	0
222-012-762-001	Weight	9
222-012-765-105	Weight	1
222-012-769-101	Race	2
222-020-627-001	No Step Sticker	1
222-020-881-101	Bushing	1
222-020-951-101	Carriage	2
222-020-952-101	Beam	2
222-025-026-101	Pad Assy	5
222-025-026-103	Pad Assy	1
222-031-175-103	Ramp L/H	0
222-031-291-106	Hinge Half	1
222-031-291-108	Hinge Half	1
222-031-602-115	Pad	4
222-035-119-127	Plate Ballast Tail Boom	2
222-036-033-101	Wear Cap	2
222-040-160-001	Oil Filter	1
222-069-951-103	Plate	3
222-080-060-001	Master cylinder R/Brake	1
222-312-761-101	Bearing	2
222-312-751-001	Bearing	2
222-320-925-103	Cable, Release, Cargo	1
222-320-929-103	Hook Cargo	2
222-325-010-003	Air Vent	1
222-342-401-103	Seal	1
222-342-402-101	Seal	1
222-366-621-1	Fuel Filter	1
222-366-649-101	Valve, Drain	2
222-375-060-119	Regulator Voltage	1
222-375-077-113	Transmitter	1
230-020-002-103	Plate	1
230-020-811-101	Panel	1
230-062-215-101	Screen	2
230-062-215-102	Screen	2
230-062-215-103	Screen	2
230-062-215-104	Screen	2
230-063-301-101	Exhaust L/H	2
230-063-301-102	Exhaust R/H	1
230-069-900-149S	Frame *See Notes	1
230-069-919-101	Plug	2

430 PARTS AND PRICING

Part Number	Description	Quantity
230-312-001-101	Link, T/R, Long	0
230-312-001-103	Bearing P/L	2
230-362-002-102	Duct Lower R/H	0
230-365-001-103	Fan Assy	2
23004212	Shim	25
23031507	Washers	10
23039043	Spacers	3
23059566-136	Packing	1
23059566-142	Packing	1