


MAINTENANCE MANUAL



BBJ-1-032

Floor Plan
Figure 1

Effectivity: S/N 29273

25-00-00

Page 3/4
Jul 15/99